
SNR-070 Range

0 - 5#

SNR-071 Range

0 - 10#



## NOTES:

- Requires 2 conductor #24 AWG shielded cable Belden 9501 or equal up to 2000' in length. Ground shield at control panel end only. Insulate shield at sensor end.
- 2) Installation of a service valve for replacement and maintenance is strongly recommended. Attached electrical conduit must be fully supported - the sensor must not carry any of the conduit's weight. Avoid mounting in a prone position in which the sensor can be damaged or broken off.

